



100cm Retractable Banner Setup Instruction Sheet


Step 1: Take everything out of the bag (1 banner case, 1 set of pole)




Step 2: Turn the two legs 90 degrees so it looks like a "H" when you look at it from the top and place it on the floor.




Step 3: Connect the three-section pole into one long pole




Step 4: Slide/Twist the pole into the hole on the banner stand so that it is sticking out from the stand. **Make sure it goes all the way down!**



Step 5: Stand behind the stand. Secure the stand by placing foot on one of the legs.



Step 6: Pull up the banner and sit the banner hardware into the pole slot. Make sure the banner hardware is sitting *firmly* into the slot!



To disassemble: Reverse Step 1 through 6. **DO NOT** let go of the banner to ensure banner retracts smoothly.