



30 West Beaver Creek Rd., Unit 6, Richmond Hill ON, L4B 3K1
Tel: 905-482-0588 Fax: 905-889-2278 E-mail: info@artsoft.ca

## 120cm Retractable Banner Setup Instruction Sheet

<u>Step 1:</u> Take everything out of the bag (1 banner case, 2 sets of poles)


<u>Step 2:</u> Turn the two legs 90 degrees so it looks like a "H" when you look at it from the top and place it on the floor.





Step 3: Connect the three-section poles into two separate long poles


**Step 4:** Slide/Twist the poles into the holes on the banner stand so that it is sticking out from the stand.






<u>Step 5:</u> Stand behind the stand. Secure the stand by placing foot on one of the legs.

<u>Step 6:</u> Pull up the banner and sit the banner hardware into one of the pole slot. Carefully do the same with the second pole. Make sure the banner hardware is sitting *firmly* into the slots!





**To dissemble:** Reverse Step 1 through 6. **DO NOT** let go of the banner to ensure banner retracts smoothly.