


120cm Retractable Banner XL Setup Instruction Sheet

Step 1: Take everything out of the bag (1 banner case, 2 sets of mini poles)




Step 2a: Connect the three-section poles. (x2)

2b: Slide/Twist the poles into the holes on the banner stand so that it is sticking out from the stand.




Make sure it goes all the way down!


Step 3: Stand behind the banner and tilt the pole towards you, then pull out the banner. **DO NOT** let go of either the poles or the banner until it is firmly secured into the slots.



Step 4: Pull up the banner and sit the banner hardware into one of the pole slot. Carefully do the same with the second pole. Make sure the banner hardware is sitting *firmly* into the slots!



Step 5: Set the banner back up. Make sure the stand is sitting firmly on the ground. Turn the two legs 90 degrees so that it looks like a "H".



To disassemble: Reverse Step 1 through 5. **DO NOT** let go of the banner to ensure banner retracts smoothly.