



(RB33) 85cm Retractable Banner Setup Instruction Sheet


Step 1: Take everything out of the bag (1 banner case, 1 set of pole)




Step 2: Connect the three-section pole into one long pole




Step 3: Twist the pole into the hole on the banner stand. **Make sure it goes all the way down**




Step 4a: Twist the two legs 90 degrees. Then place your foot on the case and pull the banner up. **DO NOT** let go as it may damage the graphic.



Step 4b: If reaching the top of the pole is not possible, leave the legs in the closed position and tilt the banner towards you and then pull up.



Step 5: Sit the banner hardware into the pole slot. Make sure the banner hardware is sitting *firmly* into the slot before letting go! Then twist the legs 90 degrees if you haven't done so already.



To disassemble: Reverse Step 1 through 5. **DO NOT** let go of the banner to ensure the graphic does not get damaged.