


8ft / 10ft Fabric Wall Flex Curved Setup Instruction Sheet

Setting up the frame

- 1) Unpack the frame and make sure you have all the parts.
- 2) Put the frame together according to the diagram below.



Assembling the fabric

- 1) Unzip the fabric and slide the fabric over the frame.
- 2) Pull up the fabric so it covers the whole frame. Zip up the fabric to secure.

To Disassemble: Reverse Setup Instructions.



How to wash: The fabric print can be placed into the washing machine with a small amount of detergent and then dried in the dryer using gentle tumble and low heat settings.