


30 West Beaver Creek Rd., Unit 6, Richmond Hill ON, L4B 3K1 Tel: 905-482-0588 Fax: 905-889-2278 E-mail: info@artsoft.ca

Pinwheel Hanging Sign Setup Instruction Sheet.

Step 1: Setup the 3 franes individually

- 1) Connect the Top Rails matching the number (i.e. T1 with T1). Make sure the push pin is locked.
- 2) Repeat for the Bottom Rails (i.e. B1 with B1).
- 3) Install the curved middle support beam with a screw through the bottom beam using an allen key and a screw eye through the top beam. Note: Make sure the arch of the vertical beam faces inside.
- 4) Repeat the above steps for the 2 remaining frames.








www.ArtSoft.ca


30 West Beaver Creek Rd., Unit 6, Richmond Hill ON, L4B 3K1 Tel: 905-482-0588 Fax: 905-889-2278 E-mail: info@artsoft.ca

Step 2: Installing the graphic

1) Unzip the graphic and spread it out on the ground.



- 2) Place the frame onto the middle way of the graphic. Also, make sure the hole on the graphic line up with the screw eye.
- 3) Remove the screw eye and pull the graphic over it and re-insert the screw eye to secure it.



4) Zip up the graphic.




www.ArtSoft.ca

30 West Beaver Creek Rd., Unit 6, Richmond Hill ON, L4B 3K1 Tel: 905-482-0588 Fax: 905-889-2278 E-mail: info@artsoft.ca

Step 3: Connecting the 3 Frames

- 1) Lineup the 3 frames so that the holes screw holes are aligned.
- 2) Insert the **black** screws and tighten securely with an allen key.
- 3) Secure the Quick Link onto the screw eye.
- 4) Use Harness Ring to link all 3 cables together for hanging if necessary.



To Disassemble: Reverse Set Up instructions.